

PROPER USAGE AND MAINTENANCE

Proper usage and maintenance is vital for getting the most out of the valuable resources we have. Our designs are made to last for generations, but just like everything else, they need a little care to get there.

TEAK

Origin

Teak is commonly found in Southeast Asia, Central and South America. Our FSC-certified Teak comes from Central America, Brazil and Indonesia, while our non-certified teak comes from plantations in Southeast Asia and Trinidad; managed to sustain a renewable and reliable supply of wood.

Why

Teak is a heavy, hard and sturdy type of wood. The high content of natural oils makes it highly resistant and it is therefore a good choice for household articles and furniture.

Cleaning

For regular cleaning use a suitable cleaning agent for wood.

Maintenance

As the wood is untreated the surface will patinate and change colour over time into a beautiful silvery grey. To maintain untreated wood, it is a good idea to use sandpaper (grit 120-150) once or twice a year.

CANVAS

Why

Canvas is a strong fabric made of good quality cotton, which makes it a good choice for hammocks and upholstery. Be aware that the fabric will stretch approximately 10%.

Washing instructions

Stubborn stains can be removed using a spot remover or a wrung cloth. Note: The padded cushion and back rest are not suited for washing in machine. The unpadded seat cover is machine washable at max 40° C. Use a delicate program. Do not tumble dry. To make sure that the canvas still fits the Director's Chair place the canvas on the chair while still humid. Always bring your Director's Chair inside at night or in rainy weather.